

## ASSEMBLY INSTRUCTIONS FOR YOUR HUDSON FLOOR LAMP

## **IMPORTANT SAFETY INSTRUCTIONS:**

- \* This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- \* Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- \* Switch power off and remove plug from the wall outlet before replacing the bulb.
- \* This lamp is UL rated for dry locations.

## **ASSEMBLY INSTRUCTIONS:**

NOTE: Do not connect electricity until lamp is fully assembled.

- 1. Unpack all parts and remove packing materials.
- 2. Pulling cord taut from below base (H) to avoid damage to cord, thread column (G) onto base (H).
- 2. Remove finial (A) from shade riser (C). Thread shade riser (C) onto socket housing (D).
- 3. Place shade (B) onto shade riser (C).
- 4. Thread finial (A) back onto shade riser (C) to secure placement of shade.
- 5. Insert two 150W Max. Type A, medium base bulbs into the sockets (E).
- 6. Insert polarized plug (G) into wall outlet.
- 7. Use pull chains (F) to control power to the lamp.

