

## ASSEMBLY INSTRUCTIONS:

**NOTE:** All wires are connected. When unpacking be careful not to pull wires as a bad connection may result. Do not connect the electricity until lamp is fully assembled.

Unpack and place all parts on a soft surface.

1. Attach metal part (B) into bottom column (A).
2. Thread middle column (E) into bottom column (A)
3. Use allen wrench (C) to tighten the screw (D)..
4. Attach metal part (F) into middle column (E).
5. Thread upper column (G) into middle column (E).
6. Thread double sockets (H) into upper column (G)
7. Thread stem (I) into double sockets (H).
8. Attach shade (J) onto stem (I).
9. Screw the finial (K) onto stem (I) to tighten shade (J).
10. Install the bulb (not included), Don't use greater than 150 watts 3-way Type A bulb.

**Note:** Pull any excess wire through bottom of the lamp.

**Caution:** To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.

**Note:** Turn the power off (unplug from the wall outlet) Before replacing the bulb, make sure the bulb has had sufficient time to cool down. Do not subject the lamp to any shock while lit as shattering of bulb may result.

## IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock, this plug will fit in a polarized outlet only one way.

If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless the plug can be fully inserted.

**DO NOT ALTER THE PLUG.**

