

ASSEMBLY INSTRUCTIONS FOR YOUR
Jonathan Adler
MYKONOS OVAL CHANDELIER

IMPORTANT SAFETY INSTRUCTIONS:

- *These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.
- *WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**
- *Turn off power at switch before replacing bulbs.
- *If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.
- *This fixture is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts from carton. Do not throw away any parts.
3. Remove quick link (F) from hang straight (E). Keep quick link (F) attached to loop (G).
4. Remove mounting plate (A) from canopy (C) by removing canopy screws (D). Set canopy screws (D) aside.
5. Carefully pull the wiring from the ceiling outlet box. Thread the wires through the center hole in mounting plate (A).
6. Affix mounting plate (A) to ceiling outlet box with mounting screws (B) provided.
7. Measure desired drop for fixture to hang and add/remove extension tubes (H) as needed. Guide wiring through extension tubes before threading tubes together. ****TO ADD/REMOVE EXTENSIONS: (Un)Thread the threaded tube of one extension into/out of the threaded opening of the next extension. Make sure electrical cord is pulled tight when threading extensions together to prevent damage to the wiring.**
8. Pull cord taut from above and thread bottom extension (H) onto threaded tube exiting housing (I).
9. Secure quick link (F) to hang straight (E). Guide wire exiting top extension (H) through the center of the hang straight (E) and canopy (C). Cut the cord to the desired length to make electrical connections. Note: at least 14 inches of wire is needed to make proper electrical connections.
10. Lift canopy (C) to mounting plate (A) and make proper electrical connections described in steps 11 - 13. A LICENSED ELECTRICIAN IS RECOMMENDED.
11. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (M) and tightly wrap connection with electrical tape.
12. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (M) and tightly wrap connection with electrical tape.
13. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (M) and tightly wrap connection with electrical tape.
14. Carefully push wire connections back into ceiling outlet box. Slide canopy (C) over mounting plate (A). Thread screws (D) into holes in canopy (C) to secure fixture to ceiling.
15. Remove flange (J) from socket (L). Place shade (K) onto socket (L). Thread flange (J) back onto socket (L) to secure shade to fixture. Repeat step for remaining shades.
16. Install eight 60W MAX. Type B, candelabra base bulbs into the sockets (L).
17. Reconnect main electrical supply at the fuse box/ circuit breaker and test fixture.

ASSEMBLY INSTRUCTIONS FOR YOUR
Jonathan Adler
MYKONOS OVAL CHANDELIER

