

ASSEMBLY INSTRUCTIONS FOR YOUR RICO ESPINET BUMPER FLOOR LAMP

IMPORTANT SAFETY INSTRUCTIONS:

- * This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- * Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- * Switch power off and remove plug from the wall outlet before replacing the bulb.
- * This lamp is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp base on a level surface.
2. Align column (F) with base (G). Place threaded tube located at the end of column (F) through hole in the center of base (G). Pull cord taut from below the base (G) to prevent damage to the wire.
3. Hold column (F) and base (G) together and carefully turn the lamp onto its side. Slide washer (H) onto threaded tube. Thread nut (I) onto threaded tube and tighten with wrench (O).
4. Join wire connectors (K) and (L).
5. Peel protective backing from felt (J). Press felt firmly against base (G).
6. Carefully turn lamp into upright position.
7. Remove flange (E) from housing (B).
8. Slide shade (D) over socket (C) and housing (B). Thread flange (E) back onto the housing (B) to secure shade in place.
9. Install one 150W max., type A, medium base bulb into the socket (C).
10. Adjust shade position by swiveling at joint (A).
11. Remove protective plastic from plug (N).
12. Insert plug (N) into wall outlet.
13. Use full range dimmer (M) to control power to the lamp.

****To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners.****

