

ASSEMBLY INSTRUCTIONS FOR YOUR  
**Jonathan Adler**  
SMALL VIENNA CHANDELIER

IMPORTANT SAFETY INSTRUCTIONS:

\*These instructions are provided for your safety. It is very important that they are read completely before beginning the installation of your fixture.

**\*WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**

\*Turn off power at switch before replacing bulbs

\*If any special control devices are used with this fixture, follow the instructions carefully to assure full compliance with N.E.C. requirements. If there are any questions, contact a qualified electrical contractor.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY AT FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts from carton. Do not throw away any parts.
4. Remove quick link (G) from hang straight (F). Keep quick link (G) attached to loop (H).
5. Remove cross bar (A) (with threaded nipple (C) and hang straight (F) attached) from canopy (D). Do this by unthreading collar (E) from hang straight (F). Canopy (D) will slip over hang straight (F). Set the canopy (D) and collar (E) aside.
6. Affix cross bar (A) (with threaded tube (C) and hang straight (F) attached) to ceiling outlet box using screws (B) provided.
7. Measure desired drop for fixture to hang and add/remove extension tubes (I) as needed. Guide wiring through extension tubes before threading tubes together.
- \*\*TO ADD/REMOVE EXTENSIONS: (Un)Thread the threaded nipple of one extension into/out of the threaded opening of the next extension. Make sure electrical cord is pulled tight when threading extensions together to prevent damage to the wiring.
8. Pull cord taut from above and thread extension (I) onto nipple exiting housing (J).
9. Slip collar (E) over extensions (I) so it rests on housing (J). Slip canopy (D) over extensions (I) so it also rests on housing (J).
10. Lift fixture to ceiling and secure quick link (G) to hang straight (F). Guide wire exiting top extension (I) through hang straight (F) and threaded tube (C).
11. Make proper electrical connections described in steps 12 - 14. A LICENSED ELECTRICIAN IS RECOMMENDED.
12. Attach ground wire from fixture (green or silver in color) to ground wire from outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
13. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
14. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
15. Carefully push wire connections back into ceiling outlet box.
16. Slide canopy (D) up extensions (I) and hold flush against ceiling. To secure position of canopy (D), slide collar (E) up the extensions and thread it onto hang straight (F). Turn until hand tight.
17. Install four 60W MAX. Type B, candelabra base bulbs into the sockets (P).
17. To install glass panels (N), unthread ball details (O) from arms (M).
18. Carefully slide glass panels (N) onto arms (M). NOTE: Due to variation in the thickness of glass, it may be necessary to thread washer (L) out towards the end of arm (M) so glass panel (N) can be held securely in place between the ball detail and the washer. Do not over tighten ball detail (O) when installing glass as doing so can cause the glass panels to crack.
19. Reconnect main electrical supply from the fuse box/ circuit breaker and test the fixture.

\*\*\*To clean, use soft cloth only. Do not use any chemical or abrasive cleaners.\*\*\*

ASSEMBLY INSTRUCTIONS FOR YOUR  
**Jonathan Adler**  
SMALL VIENNA CHANDELIER

