

ASSEMBLY INSTRUCTIONS FOR YOUR ANDROMEDA TABLE LAMP

IMPORTANT SAFETY INSTRUCTIONS:

- * This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- * Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- * Switch power off and remove plug from the wall outlet before replacing the bulb.
- * This lamp is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp base on a level surface.
2. Remove finial (A) from harp (C). Squeeze harp (C) inward and place into the opening of saddle (D).
3. Place shade (B) onto harp (C). Thread finial (A) back onto the harp to secure the shade to the lamp.
4. Thread rods (E) into housing (F) until hand tight. Note: do not over tighten as this could cause damage to rods. Note: Grasp acrylic rods at base, near threads to avoid damage to acrylic and cap. Do not force rods into housing. If you experience difficulty threading a rod into the housing at chosen spot, don't try to force the parts to thread together. Instead, try threading the rod into a different opening in the housing.
5. Install one 150W max., type A, medium base bulb into the socket.
6. Remove protective plastic from plug (G).
7. Insert plug (G) into wall outlet.

