

ASSEMBLY INSTRUCTIONS FOR YOUR  
**MICHAEL BERMAN LIMITED**  
**BOND OUTDOOR PENDANT**

**IMPORTANT SAFETY INSTRUCTIONS:**

- \* These instructions are provided for your safety.
- \* It is very important that they are read completely before beginning the installation of your fixture.
- \* **WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**
- \* Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- \* This fixture is UL rated for wet locations.

**ASSEMBLY INSTRUCTIONS:**

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts carefully from the carton. Do not throw away any parts.
3. Remove hang straight (F) from chain (H) by detaching quick link (G) from chain (H), while keeping cross bar (A), threaded tube (C), canopy (D) and collar (E) together.
4. Measure desired drop for fixture to hang and add/remove chain links (H) with chain break tool (not included).
5. Reattach quick link (G) to the top chain link (H).
6. Unthread collar (E) from hang straight (F), and carefully slide it down chain (H) so it rests on loop (I).
7. Slide canopy (D) down chain (H) so it rests on top of loop (I).
8. Affix cross bar (A) (with threaded tube (C) and hang straight (F) attached) to ceiling outlet box using cross bar screws (B) provided.
9. Lift fixture to ceiling and secure quick link (G) to hang straight (F). Guide the wire exiting the fixture through the center of collar (E) and canopy (D). Continue to guide the wire through chain (H), quick link (G) and through the center of hang straight (F) and threaded tube (C).
10. Cut the cord to the desired length to make electrical connections. At least 8" of wire will be needed to make proper electrical connections.
11. Make proper electrical connections described in steps 12-14. A LICENSED ELECTRICIAN IS RECOMMENDED.
12. Attach ground wire from the fixture (green or copper in color) to the ground wire in outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
13. Attach hot wire from fixture (black in color, or smooth side of wire) to hot wire from ceiling outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
14. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from ceiling outlet box. Fasten wires together with wire nut (K) and tightly wrap connection with electrical tape.
15. Gently push wire connections back into ceiling outlet box. Slide canopy (D) up chain (H) and hold firmly against ceiling. Slide collar (E) up chain (H) and thread onto hang straight (F), securing canopy (D) against ceiling.
15. Install one 100W MAX. Type A, medium base bulb into socket (J).
16. Reconnect main electrical supply from the fuse box/ circuit breaker and test the fixture.

**\*\* To clean, use soft cloth only. Do not use any chemical or abrasive cleaners. \*\***

