


## ASSEMBLY INSTRUCTIONS FOR YOUR ABBEY BRONZE SWING ARM TABLE LAMP



## **IMPORTANT SAFETY INSTRUCTIONS:**

- \* This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- \* Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- \* Switch power off and remove plug from the wall outlet before replacing the bulb.
- \* This lamp is UL rated for dry locations.

## **ASSEMBLY INSTRUCTIONS:**

NOTE: Do not connect electricity until lamp is fully assembled.

- 1. Unpack all parts and remove packing materials. Place lamp base on a level surface.
- 2. Install one 60W max., type A, medium base bulb into the socket (B).
- 3. To attach shade (A) to fixture, open shade clip, located inside shade (A). Slide clip over bulb until clip reaches a resting position. (DO NOT ATTACH SHADES UNLESS POWER TO FIXTURE IS OFF AND BULB IS COOL.)
- 4. Carefully swivel arms (C) and (D) to desired positions.
- 5. Remove protective plastic from plug (F).
- 6. Insert plug (F) into wall outlet. Control power by operating switch (E) on cord.