


## ASSEMBLY INSTRUCTIONS FOR YOUR HERON FLOOR LAMP



### IMPORTANT SAFETY INSTRUCTIONS:

- \* This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- \* Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- \* Switch power off and remove plug from the wall outlet before replacing the bulb.
- \* This lamp is UL rated for dry locations.

### ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp on a level surface.
2. To adjust position of lamp, carefully grasp handle (A) and move shade into desired position.
3. Please note occasional tightening of allen bolts will be required to maintain proper position of the arm.  
To make adjustments, use provided wrench (D) to gently tighten the allen bolts on the arm. The allen bolts have been circled in the illustration above.
4. Remove protective plastic from plug (C).
5. Insert polarized plug (C) into wall outlet.
6. Turn lamp on and off by touching sensor (B).

Note: This lamp comes with a non-replaceable LED panel.

**\*\* To clean, use a soft cloth only. Do not use any chemical or abrasive cleaners. \*\***

