

ASSEMBLY INSTRUCTIONS FOR YOUR NOVA FLOOR LAMP

IMPORTANT SAFETY INSTRUCTIONS:

- * This lamp has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Do NOT alter the plug.
- * Do not use with an extension cord unless the plug from the lamp can be fully inserted into the extension cord receptacle.
- * Switch power off and remove plug from the wall outlet before replacing the bulb.
- * This lamp is UL rated for dry locations.

ASSEMBLY INSTRUCTIONS:

NOTE: Do not connect electricity until lamp is fully assembled.

1. Unpack all parts and remove packing materials. Place lamp base on a level surface.
2. Remove flange (D) and plastic washer (C) from socket (A).
3. Slide glass shade (B) over socket (A). Holding glass shade in place, slide plastic washer over socket and thread flange (D) back onto the socket to secure the shade to the lamp.
4. Install one 100W max., type A, medium base bulb into the socket (A).
5. Remove protective plastic from plug (D).
6. Insert plug (D) into wall outlet. Control power to lamp by operating full range dimmer on cord.

