


ASSEMBLY INSTRUCTIONS FOR YOUR WILLIAMSBURG TAYLOE WALL SCONCE



IMPORTANT SAFETY INSTRUCTIONS:

- * These instructions are provided for your safety.
- * It is very important that they are read completely before beginning the installation of your fixture.
- * **WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**
- * Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.

ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts from carton and discard packing materials. Place the parts on a level surface.
3. Remove mounting plate (A) from backplate (B) by unthreading screws (C). Set screws (C) aside.
4. To install glass panels, unthread screws (H) to loosen brackets (I) as shown in Illustration A. NOTE: Do not unthread screws (H) completely from metal frame (K) as it is unnecessary.
5. Carefully insert glass panels (J) into the space between brackets (I) and metal frame (K). Carefully tighten screws (H) back into metal frame (K) to secure glass panels in place. NOTE: Do not over tighten screws (H). Doing so can cause the glass panels to break.
6. Align mounting plate (A) with wall outlet box. Hold mounting plate (A) in a level position against the wall. Using a pencil, mark the location of the holes (L) at the top and bottom of the mounting plate onto the wall.
7. Drill small holes at marked locations on the wall. Holes should be sized so they accommodate wall anchors (F), provided. Insert wall anchors into drilled holes.
8. Carefully pull wires from the wall outlet box and thread them through the center hole in mounting plate (A).
9. Affix mounting plate (A) to the wall outlet box with screws (D). For additional support, thread mounting screws (G) through holes (L) and into wall anchors (F).
10. Lift backplate (B) to mounting plate (A) and make the proper electrical connections noted in steps 11 through 13.
A LICENSED ELECTRICIAN IS RECOMMENDED.
11. Attach ground wire from fixture (green or copper in color) to ground wire from outlet box. Fasten wires together with wire nut (E) and tightly wrap connection with electrical tape.
12. Attach hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (E) and tightly wrap connection with electrical tape.
13. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (E) and tightly wrap connection with electrical tape. Gently push wire connections back into the wall outlet box.
14. Place backplate (B) over mounting plate (A). Use screws (C) to secure the fixture to the mounting plate.
15. Install two 40W Max., Type B, Candelabra base bulbs into the sockets.
16. Reconnect main electrical supply at the fuse box/ circuit breaker and test the fixture.

** To clean, use soft cloth only. Do not use any chemical or abrasive cleaners. **