

## ASSEMBLY INSTRUCTIONS FOR YOUR MICHAEL BERMAN LIMITED BOND OUTDOOR SCONCE

### IMPORTANT SAFETY INSTRUCTIONS:

- \* These instructions are provided for your safety.
- \* It is very important that they are read completely before beginning the installation of your fixture.
- \* **WE STRONGLY RECOMMEND INSTALLATION BY A LICENSED ELECTRICIAN.**
- \* Turn off power at switch before replacing bulbs, making sure fixture has had sufficient time to cool down.
- \* This fixture is UL rated for wet locations.

### ASSEMBLY INSTRUCTIONS:

1. SHUT OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/ CIRCUIT BREAKER.
2. Remove all parts carefully from the carton. Do not throw away any parts.
3. Remove mounting plate (A) from backplate (D) by unthreading screws (E). Set screws (E) aside.
4. Place the mounting plate (A) against the mounting surface so it is aligned with the wall outlet box. Once aligned, check to make sure that the mounting plate is level. When proper placement has been confirmed, use a pencil to mark the locations of the mounting plate support holes (B) onto the mounting surface.
5. Set the mounting plate aside and drill small holes at the marked locations. Holes should be sized so anchors (K) fit securely inside.
6. Push anchors (K) into the holes.
7. Carefully pull wires from the wall outlet box and thread them through the center hole in mounting plate (A).
8. Affix mounting plate (A) to wall outlet box with mounting screws (C) provided.
9. For additional support, thread mounting screws (L) through support holes (B) and into wall anchors (K).
10. Lift the backplate (D) to the mounting plate and make the proper electrical connections noted in steps 11 through 13. A LICENSED ELECTRICIAN IS RECOMMENDED.
11. Attach ground wire from fixture (green or copper in color) to ground wire from outlet box. Fasten wires together with wire nut (J) and tightly wrap connection with electrical tape.
12. Attache hot wire from fixture (black in color or smooth side of wire) to hot wire from outlet box. Fasten wires together with wire nut (J) and trightly wrap connection with electrical tape.
13. Attach neutral wire from fixture (white in color or ribbed side of wire) to neutral wire from outlet box. Fasten wires together with wire nut (J) and tightly wrap connection with electrical tape. Gently push wire connections back into the wall outlet box.
14. Place backplate (D) over mounting plate (A). Use screws (E) to secure the backplate to the mounting surface.
15. Install one 100W max., type A, medium base bulb into the socket (H).
16. Remove screws (G) and set them aside. Lift shade (I) to canopy (F) and align holes. Thread screws (G) back into canopy (F) to secure shade. Turn until hand tight.
17. Reconnect main electrical supply at the fuse box/ circuit breaker and test the fixture.

